


EPC SERIES TRANSFORMER

OPERATING INSTRUCTION:



1. TIMER ON TIMER OFF:

- Push in all trippers on dial between desired "ON" time.
- Turn dial clockwise until time arrow is pointing at correct time of day.

2. AUTOMATIC CONTROL WITH PHOTOCELL:

- Remove protective cover from photocell.
- To control lights - Set the timer to turn on before dark and the photocell will activate the lights when it gets dark. Lights can be turned off by the timer at a preset time, or push in all trippers and photocell will turn off lights at dawn.

3. CIRCUIT BREAKERS:

- A circuit breaker will trip if there is a short, or if total lamp wattage installed exceeds rating.
- To reset breaker - Turn breaker to On position
- If breaker trips again, check for an overload or for a short circuit.

4. NOTE: Photo cell has a delay of up to 30 ± 15 sec.

ISOLATED WINDING TYPE TRANSFORMER

When used to supply power to fountain lighting, this transformer must be plugged into a (GFCI) ground fault circuit interrupter outlet located at least 10 ft. (3.05M) from the inside wall of the fountain.

NOTE: IN CASE OF POWER FAILURE TIMER MUST BE RESET.



Intertek
3062751

LANDSCAPE TRANSFORMER
LOW VOLTAGE

SUITABLE FOR WET LOCATIONS

THIS UNIT PROTECTED WITH A THERMAL PROTECTOR AND WILL AUTOMATICALLY SHUT OFF IF IT OVERHEATS. IF THE UNIT CYCLES ON AND OFF, IT SHOULD BE CHECKED BY A QUALIFIED SERVICE PERSON.

**MOUNT THIS UNIT NO LESS THAN 1 FT. ABOVE
GROUND LEVEL WITH THIS ARROW POINTED UP**



COVER MUST BE INSTALLED